Krups Fast Touch Coffee and Spice Grinder

Owner's Manual



Table of Contents

Table of Contents	2
Warnings	3
Introduction	4
Specifications	5
Instructions	7
Frequently Asked Questions	9
Citations	10

Warnings

For your safety, please remember the following:

- IN CASE OF BODILY INJURY, CALL 911.
- Unplug the Krups Fast Touch Coffee and Spice Grinder when not in use.
- Keep all body parts away from the blade when the grinder is plugged in.
- Unplug the grinder before cleaning.
- Activate grinder only using the grind button.
- Do not use grinder for purposes other than grinding coffee beans, spice, herbs, and nuts.
- The grinder is intended for household use only.

Introduction

Everyone knows coffee is best when made from freshly ground beans. The Krups Fast Touch Coffee Grinder ensures your best coffee is only the push of a button away.

The coffee grinder comes in two parts: the body and the cap. The body houses the device's single stainless steel blade and holds the beans or grounds, while the removable cap features the button powering the grinder. The grinder is electric, so no manual labor or batteries are required.

Push the grind button and watch as the stainless steel blade spins and turns your whole coffee beans into ready-to-be-brewed grounds. In only a few seconds, you can have enough fresh grounds for up to a full pot of coffee (12 cups).

Little maintenance is required. The coffee grinder is small and requires little space to operate or store.

The Krups Fast Touch Coffee Grinder is a must-have for any coffee fan looking to explore new brews and flavors.

Specifications

Appearance

The grinder is made of two primary parts: a black glossy body and a removable clear cap. The outside of the coffee grinder is mostly plastic and features an oval design. The body houses a stainless-steel blade and grinding tray and also features the Krups branding and the electrical cord for powering the device. The clear cap covers the tray while grinding and includes the black grinding button which activates the blade when placed on top of the body.



Figure 1 - Outer anatomy of grinder



Figure 2 - Anatomy of the grind portion

Technical

- Weight: 1.5 pounds
- Dimensions: 6.69" x 3.15"
- · Features a 200-watt motor
- Powered by a standard 120-volt outlet (The grinder does not use batteries.)

Usage

With the push of a button and in a matter of seconds, the coffee grinder converts your whole coffee beans into fresh grounds for up two 12 cups ready for brewing. The coffee grinder can also grind up to 3 ounces of spices, nuts, and herbs. Users determine the coarseness or fineness of the final product with how long they hold the grinding button. To ensure safety, attempt grinding only when the cap is united with the body.

Instructions

Please be sure to read the **Warnings** section on Page 3 of this manual before proceeding.

Preparation

- 1. Remove the grinder from storage and leave unplugged.
- 2. Place the grinder on a flat, stable surface and remove the cap.
- 3. Add up to 12 scoops (or 12 tablespoons) of whole coffee beans (or up to 3 oz. of spices, nuts, or herbs).
- 4. Secure cap onto the body of the grinder.



Preparation 3.

Use

- 1. Plug the grinder into a standard electric outlet.
- 2. Press and hold the grind button until coffee has been ground to preference.
- 3. Unplug the grinder.



4. Remove cap and scoop or dump coffee or spice into coffee filter or storage container.

After Use

- 1. Shake out any excess coffee or spice. Using a damp cloth, clean the blade and the grind tray.
- 2. Secure cap onto body of the grinder.
- 3. Store until next use.



After Use 1.

Frequently Asked Questions

Does the grinder have multiple speeds or power settings?

No. The grinder has only one speed. There are no other options.

Can the grinder operate using batteries?

No. The grinder is electric and can be powered only by the power cord.

For more information on the Krups Fast Touch Coffee Grinder, please visit the Krups website: https://www.krupsusa.com/BREAKFAST-APPLIANCES/COFFEE-GRINDERS/Fast-Touch-Electric-Coffee-and-Spice-Grinder-F2034251/p/1500813248

Citations

- Photos:
 - https://www.crateandbarrel.com/krups-fast-touch-coffee-grinder/s519208
- Technical information:
 - https://www.walmart.com/ip/KRUPS-Fast-Touch-Electric-Coffee-and-Spice-Grinder-With-Stainless-Steel-Blades-F2034251/38470909
- Photos and technical information:
 - https://www.target.com/p/krups-electric-spice-and-coffee-grinder-f2034251/-/ A-52731838#lnk=sametab